

All log out material shall be moved and stabilized outside of clearing limits. 1—Foot Beyond Top of Cut Outside Clearing Limits or Toe of Fill

Material shall be placed to where it will not create any obstructions.

Malheur and Wallowa—Whitman National Forest — February 2006